



## SZKŁO HARTOWANE SPIGEN ALM GLAS.TR 2-PACK GALAXY A55 5G CLEAR

Product code: 8809971227070-AGL07775

EAN: 8809971227070



Tempered glass with a revolutionary installation method - if you have been terrified by this aspect of using tempered glass until now, your problems have just been solved!

The tempered glass from the "AlignMaster" series by Spigen has been secured with a perfectly cut mounting frame for the front of the phone, allowing you to position it perfectly on the screen. The manufacturer has simplified the installation process to such an extent that it is fully intuitive for every user.

Glas.TR AlignMaster is a thin coating that has been hardened to a hardness of 9H during the production and tempering process.

This makes it resistant to scratches even when in contact with sharp objects like keys or knives.

The glass is coated with an oleophobic and hydrophobic layer, which prevents fingerprints and other contaminants from being left on the screen.

It is crystal clear and perfectly reproduces displayed colors.

It also does not affect touch sensitivity and has exceptional smoothness, making it a pleasure to glide your finger across the screen. The glass is particularly dedicated to protecting the screen from scratches and minimizes the risk of screen damage during unexpected falls.

### Check how to install:

[https://www.youtube.com/watch?v=1Au-ERS\\_sXo&ab\\_channel=FlavourDesign](https://www.youtube.com/watch?v=1Au-ERS_sXo&ab_channel=FlavourDesign)

\* The glass/film is cut only for the flat part of the display with a raised structure, according to and based on the die prepared by the manufacturer of the specific phone model. Only such cutting of the film/glass will ensure complete compatibility with our protective accessories.

\*\* Due to the various milling of the display edges, after installing the protective film/glass on the screen, a delicate air halo may form around the screen. This is a natural situation and depends on the screen itself.

### INSTALLATION INSTRUCTIONS:

1) Start the installation in the bathroom right after a shower - the steam will absorb all the dust from the atmosphere and it will not interfere with your installation.

- 2) Clean and degrease the surface of the screen thoroughly, then polish it to a shine with a dry cloth.
- 3) Place the frame with the unsealed glass on the front of the phone.
- 4) Remove the frame along with the protective film. Get rid of air bubbles by pressing the entire surface in circular motions for several seconds. Do this so that the adhesive layer bonds with the screen as strongly as possible.

**PRODUCT FEATURES:**

- 100% Original
- Packed in original packaging
- Exceptional ease of installation thanks to the mounting frame
- Hardness 9H
- 2.5D milled edges that are pleasant to the touch
- Additional oleophobic layer
- Ideal clarity
- Does not affect touch functionality
- Dimensions: 157x73 mm

**SET INCLUDES:**

- 2 x Spigen Glas.TR AlignMaster Glass
- 1 x Installation kit