



## SZKŁO HARTOWANE SPIGEN ALM GLAS.TR 2-PACK GOOGLE PIXEL 8A CLEAR

Product code: 8809971223775-AGL07464

EAN: 8809971223775



Tempered glass with a revolutionary installation method - if you have been scared by this aspect of using tempered glass until now, your problems have just been solved!

The tempered glass from Spigen's "AlignMaster" series is secured with a perfectly cut mounting frame for the front of the phone, allowing you to position it perfectly on the screen. The manufacturer has simplified the installation process to the point that it is fully intuitive for any user.

Glas.TR AlignMaster is a thin coating that has been hardened to 9H hardness during production and tempering.

This makes it resistant to scratches even when in contact with sharp objects like keys or knives.

The glass is coated with an oleophobic and hydrophobic layer that prevents fingerprints and other contaminants from being left on the screen.

It is crystal clear and perfectly reproduces displayed colors.

It also does not affect touch sensitivity and has exceptional smoothness, making finger movement across the screen a pleasure. The glass is especially dedicated to protecting the screen from scratches and minimizes the risk of screen damage during unexpected falls.

### **Check how to install:**

[https://www.youtube.com/watch?v=1Au-ERS\\_sXo&ab\\_channel=FlavourDesign](https://www.youtube.com/watch?v=1Au-ERS_sXo&ab_channel=FlavourDesign)

\* The glass/film is cut only for the flat part of the display with a protruding structure, according to and based on the die prepared by the manufacturer of the specific phone model. Only such cutting of the film/glass will ensure complete compatibility with our protective accessories.

\*\* Due to the various milling of the display edges, a slight air halo may form around the screen after installing the protective film/glass on the screen. This is a natural situation and depends on the screen itself.

### **INSTALLATION INSTRUCTIONS:**

1) Start the installation in the bathroom right after a shower - the steam will absorb all the dust from the atmosphere and it won't interfere with your installation.

- 2) Clean and degrease the screen surface thoroughly, then polish it to a shine with a dry cloth.
- 3) Place the frame with the unsealed glass on the front of the phone.
- 4) Remove the frame along with the protective film. Get rid of air bubbles by pressing the whole thing firmly in circular motions for several dozen seconds. Do this so that the adhesive layer bonds with the screen as strongly as possible.

**PRODUCT FEATURES:**

- 100% Original
- Packaged in original packaging
- Exceptional ease of installation thanks to the mounting frame
- 9H hardness
- 2.5D milled edges that feel nice to the touch
- Additional oleophobic layer
- Perfect clarity
- Does not affect touch functionality
- Dimensions:

**SET INCLUDES:**

- 2 x Spigen Glas.TR AlignMaster Glass
- 1 x Installation kit