



SZKŁO HARTOWANE TECH-PROTECT GLASS UV+ 2-PACK MOTOROLA EDGE 60 PRO CLEAR

Product code: 5906302368921

EAN: 5906302368921



Tech-Protect Glass UV is the highest quality tempered glass that will provide exceptional protection for your device's screen. Thanks to UV application technology, the glass perfectly adheres to the surface, eliminating the formation of air bubbles and ensuring full clarity and touch sensitivity.

With a hardness level of 9H, it effectively protects the screen from scratches, impacts, and other mechanical damage, while the special UV light-curing adhesive guarantees perfect fit and stability, even on curved screens.

The glass provides full coverage of the screen, edge to edge, without affecting image quality or color reproduction, and its smooth surface allows for full responsiveness of the touchscreen.

Tech-Protect Glass UV is the ideal solution for those looking for reliable screen protection while maintaining the aesthetics and functionality of the device.

* We do not recommend using 3D glass without any case.

** We do not recommend using glass if the case overlaps too much on the edges of the screen, there is a risk of prying.

*** The functionality of the fingerprint reader on the screen may be slightly disturbed if a film or glass coating is installed. The fingerprint reader is not fully optimized for additional coatings.

INSTALLATION INSTRUCTIONS:

- 1) Start the installation in the bathroom right after a bath - the steam will absorb all the dust from the atmosphere and it won't interfere with your installation.
- 2) Clean and degrease the screen surface thoroughly, then polish it to a shine with a dry cloth.
- 3) Use tape from the kit to cover the speaker.
- 4) Connect the UV lamp using a Type-C cable to a power source.
- 5) Pour the liquid onto the center of the device.
- 6) Install the glass as evenly as you can; you can also adjust this step before curing the surface when the liquid is on the screen with the glass.
- 7) If an air bubble appears, use a credit card and gently push it outside the glass area; do this before

curing.

8) Using the UV lamp, cure the glass along the center in five places for 15 seconds and then around the edge for 10 seconds.

9) Clean the phone from any residue of the cured adhesive.

10) If your device has a fingerprint reader on the screen, remember to remove and re-add your fingerprints after installing the glass on the screen.

11) Enjoy your well-done work!

PRODUCT FEATURES:

- 100% Original
- Packed in original packaging
- Tempered glass with a thickness of 0.3mm
- Scratch resistance 9H
- Equipped with an oleophobic coating
- Leaves no residue after removal
- Dimensions: 156 x 71 mm

SET INCLUDES:

2 x Tech-Protect Glass UV

1 x UV Lamp (without Type-C cable)

2 x Tube of adhesive

2 x Installation kit