



**VERNAGSM**

**vernagsm.pl**



## SZKŁO HARTOWANE TECH-PROTECT GLASS UV+ 2-PACK XIAOMI REDMI NOTE 14 PRO 4G 5G 14 PRO+ PLUS 5G POCO X7 5G CLEAR

Product code: 5906302361410

EAN: 5906302361410



Tech-Protect Glass UV is a high-quality tempered glass that provides exceptional screen protection for your device. Thanks to UV application technology, the glass perfectly adheres to the surface, eliminating air bubbles and ensuring full clarity and touch sensitivity.

With a hardness level of 9H, it effectively protects the screen from scratches, impacts, and other mechanical damage, while the special UV light-curing adhesive guarantees a perfect fit and stability, even on curved screens.

The glass provides full edge-to-edge coverage without affecting image quality or color reproduction, and its smooth surface allows for full responsiveness of the touch screen.

Tech-Protect Glass UV is the perfect solution for those looking for reliable screen protection while maintaining the aesthetics and functionality of the device.

\* We do not recommend using 3D glass without any case.

\*\* We do not recommend using glass if the case overlaps too much on the edges of the screen, there is a risk of prying.

\*\*\* The functionality of the in-screen fingerprint reader may be slightly disrupted if a film or glass coating is installed. The fingerprint reader is not fully optimized for additional coatings.

**See how easy it is:** <https://www.youtube.com/watch?v=2muqMWRAtwA>

### **INSTALLATION INSTRUCTIONS:**

- 1) Start the installation in the bathroom right after a bath - the steam will absorb all the dust from the atmosphere and it won't interfere with your installation.
- 2) Clean and degrease the screen surface thoroughly, then polish it to a shine with a dry cloth.
- 3) Use the tape from the kit to cover the speaker.
- 4) Connect the UV lamp using the Type-C cable to a power source.
- 5) Pour the liquid in the center of the device.
- 6) Install the glass as evenly as possible; you can also adjust this step before curing the surface when the liquid is on the screen with the glass.

- 7) If an air bubble appears, use a credit card and gently push it out of the glass area; this should be done before curing.
- 8) Using the UV lamp, cure the glass along the center in five places for 15 seconds and then around the edges for 10 seconds.
- 9) Clean the phone of any leftover cured adhesive.
- 10) If your device has an in-screen fingerprint reader, remember to remove and re-add your fingerprints after installing the glass on the screen.
- 11) Enjoy your well-done work!

**PRODUCT FEATURES:**

- 100% Original
- Packed in original packaging
- Tempered glass with a thickness of 0.3mm
- Scratch resistance 9H
- Equipped with an oleophobic coating
- Leaves no residue after removal
- Dimensions: 157 x 72mm

**THE SET INCLUDES:**

- 2 x Tech-Protect Glass UV
- 1 x UV Lamp (without Type-C cable)
- 2 x Tube of adhesive
- 2 x Installation kit